

## PD-205 Folder Navigation Procedures

Go to the menu by pressing “menu” key. In the menu, select the “Folder” item by pressing the “Play” key.

Screen pic 1



### At Folder Navigation

Press “Up” or “Down” key to browse the folder name. Press “Play” key to select the folder you want to browse. It will then go to browsing screen automatically. Press “Play” key again to start playback of all songs in the selected folder.

Screen pic 2



The 1<sup>st</sup> folder is called ‘Root’. If you select this folder, it means that all songs in all folders are selected and will be appeared in browsing screen for playing all songs in the player.

Screen pic 3



Notes:

1. You cannot browse a particular song in folder browsing inside the menu mode because once you’ve selected the folder, it goes to the browsing screen directly. All the songs in the selected folder can be browsed. Then, you can select your desired song in the browsing screen.
2. When you select to browse a particular folder, the repeat all/shuffle function will become to repeat all/shuffle the songs in this particular folder. If all the songs are expected to play repeatedly, please select the folder “Root”.
3. The folder browsing feature can function at browsing mode. In playing mode, the folder browsing feature will not exist.